

## ***Ordering Instructions for Electronic Tools***

### **Where do I order service tools?**

<http://www.nexiq.com>

### **Who can I contact for help with my ServiceMaxx software?**

Nexiq tech support can be reached at 877-905-6716.

### **What are the PC requirements for ServiceMaxx?**

ServiceMaxx can be run on most PCs with a least 512 MB RAM (1 GB preferred), 100 MB available hard drive space, and CD-ROM running in the Window® XP, Window® 7 (32 and 64 bit) operating system. The appropriate interface adapter must be used to communicate with the vehicle.

### **What are the recommended adapters for ServiceMaxx?**

- NEXIQ™ Technologies – USB-Link
- NAVCoM (Navistar's Advanced Vehicle Communication Module) Dearborn Group Technologies – DPA IV, DPA IV+
- Noregon Systems, Inc. – DLA, DLA USB
- Movimento – NAV-Linkrecommended adaptors area

### **NOTE: PLEASE SEE THE SERVICEMAXX USER MANUAL FOR CABLE INFORMATION:**

<http://www.navistarserviceinfo.com/store/Search.aspx?SearchTerms=EGES550>

### **How do I reflash a Navistar ECU with the latest software?**

Reflashing an ECU can be accomplished with an with an International™ Link Device

### **For Engines 2007-2015:**

<http://www.navistarserviceinfo.com/international-link.aspx>